PARTS LIST

for

KitchenAid®

30" ELECTRIC DROP-IN SELF CLEAN OVEN

MODEL KEDT105VBL1

▲ BL-Black Glass WH-White Glass AL-Almond Glass




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID INC.


ST. JOSEPH MICHIGAN 49085

COOKTOP PARTS For Model: KEDT105VBL1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

```
1
      3147132
                   Surface Unit, 8" (2)
                   Surface Unit, 6" (2)
      3147131
2
                   Ring, Intermediate
                   Black 8"
      3147186
                   White 8"
      3148489
      3148490
                   Almond 8"
      3147185
                   Black 6"
      3148486
                   White 6"
                   Almond 6"
      3148487
3
                   Gasket (2)
      3147188
                   6"
      3147187
5
                   Glass Top
      3148036
                   Black
      3148591
                   White
      3148592
                   Almond
6
      3148561
                   8" Seal (2)
      3148562
                   6" Seal (2)
7
      3148563
                   Hook, Seal (4)
      3147038
                   Plate, Backup
9
      3147735
                   Bracket, Switch
      254225
                   Screw \#8x1/4 (3)
10
                   Switch, Infinite
      3148949
                   6"
                   8"
      3148950
      311865
                   Screw #8-32 (8)
11
      309839
                   Seal, Shaft (4)
                   Tape, Foam
12
      3147485
13
                   Bracket, Mounting
      3147703
                   б"
      3147704
                   8 "
14
      3148397
                   Protector (4)
15
      3147190
                   Nut (4)
16
      3147191
                   Leaf Spring (4)
      3148615
                   Washer, Flat (4)
17
      3147189
                   Nut (4)
                   Lens (4)
18
      311688
19
                   Rail, Support
      3147024
                   Left
                   Right
      3147025
20
      3147061
                   Rail, Back, Support (2)
                   Screw, 8-18 \times 1/2
      313638
                   Knob, Control (4)
21
      3149116
22
      3147566
                   Cover, Top
      313638
                   Screw, 8-18 (3)
23
      258109
                   Bushing
24
                   Indicator, Light
      3148054
25
      3147037
                   Cover, Vent
26
      3149899
                   Seal, Infinite Switch (4)
```




Note: The Screws And Nuts Required To Attach A Part Are Listed Immediately Following That Part.

1	3170706	Liner, Door		
	3148443	Screw (6)		
2	3148234	Frame, Window		
	3148443	Screw, (6)		
3	3148441	Seal, Flange (2)		
	3148443	Screw (6)		
4	3148178	Glass, Reflective		
5	3148183	Seal, Window		
6	3148723	Retainer, Insulation		
7	313004	Glass, Outer		
8	3148187	Retainer, Glass (2)		
9	3148182	Bumper, (4)		
10		Glass, Panel		
	3148185	Black		
	3149049	White		
	3149050	Almond		
11	3148184	Foil		
12		Handle, Oven Door		
	3147636	Black		
	3147637	White		
	3147638	Almond		
	355515	Screw (4)		
13	3147951	Insulation		
14	3149473	Cap, Top White - Almond		
15	314235	Clip, Mtg. (2)		
16	3148680	Shield		
17	313005	Glass, Outer		
18		Frame		
	3148784	Black		
	3148785	White		
	3148786	Almond		
19		Door Top		
	3148606	Black		
	3149675	White - Almond		
	3149333	Screw (2) Black		
	9416643	Screw (2) White - Almond		

CONTROL PANEL PARTS

For Model: KEDT105VBL1



Note: The Screws And Nuts Required To Attach A Part Are Listed Immediately Following That Part.

1		End Cap, L.H.
	3148016	Black
	3148447	White
	3148449	Almond
	04.4004.5	End Cap R.H.
	3148017	Black
	3148448	White
	3148450	Almond
_	3148905	Washer, Silicone
2		Glass, Control Panel
	3148769	Black
	3148459	White
_	3148460	Almond
3		Rail, Top
	314240	Black
	3148456	White - Almond
4		Trim, Center
	3149420	Black
	3148453	White - Almond
5		End Trim, R.H. Vent Door
	3148698	Black
	3148472	White - Almond
		End Trim, L.H. Vent Door
	3148697	Black
	3148471	White - Almond
6		Vent Door
	314190	Black
	3149676	White - Almond
7	314184	Trim, Bottom
	342043	Screw (6)
9	3149882	Retainer, Glass (4)
10	310720	Bracket, Control Panel (2)
	98520	Screw (4)
12	3148647	Bracket, Control
13	3149045	Oven Control
	313806	Screw #6-32 (4)
17	3149648	Thermostat, Oven
	313808	Screw (2)
	246132	Screw (4)
20		Switch, Oven Light
	312581	Black
	3148465	White - Almond
	312796	Washer
21		Bezel, Switch
	313030	Black
	3148462	White - Almond
22	308605	Strain Relief
	98520	Screw
26		Knob, Timer (1)
	3149784	Black
	3149785	White
	3149786	Almond
31	3148102	Brace, Control Bracket
	309080	Screw $\#8-32 \times 3/8$

```
32
                Button, Set (8)
     3149780
                Black
     3149781
                White
                Almond
     3149782
                Trim, End Cap
33
     3149900
               Black
     3149901
               White
     3149902
               Almond
34
     3149142
                Shield - Air
35
     3149419
                Shield - Heat
     309080
                Screw #8-32x3/8
     98520
                Screw
36
     313316
               Seal, Backguard
```

OPTIONAL PARTS NOT INCLUDED

SPLICING WIRES--25FT. LENGTH

242820 Wire, Black 14 Ga. 150~C 242821 Wire, Blue 14 Ga. 150~C 242822 Wire, Brown 14 Ga. 150~C 242830 Wire, Brown 14 Ga. 200~C 242823 Wire, Green 14 Ga. 150~C 242824 Wire, Orange 14 Ga. 150~C 242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C 242827 Wire, Yellow 14 Ga. 150~C	242828	Wire,	Black 12 Ga. 150~C
242822 Wire, Brown 14 Ga. 150~C 242830 Wire, Brown 14 Ga. 200~C 242823 Wire, Green 14 Ga. 150~C 242824 Wire, Orange 14 Ga. 150~C 242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242820	Wire,	Black 14 Ga. 150~C
242830 Wire, Brown 14 Ga. 200~C 242823 Wire, Green 14 Ga. 150~C 242824 Wire, Orange 14 Ga. 150~C 242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242821	Wire,	Blue 14 Ga. 150~C
242823 Wire, Green 14 Ga. 150~C 242824 Wire, Orange 14 Ga. 150~C 242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242822	Wire,	Brown 14 Ga. 150~C
242824 Wire, Orange 14 Ga. 150~C 242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242830	Wire,	Brown 14 Ga. 200~C
242829 Wire, Red 12 Ga. 150~C 242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242823	Wire,	Green 14 Ga. 150~C
242825 Wire, Red 14 Ga. 150~C 242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242824	Wire,	Orange 14 Ga. 150~C
242831 Wire, Red 14 Ga. 200~C 242826 Wire, White 14 Ga. 150~C	242829	Wire,	Red 12 Ga. 150~C
242826 Wire, White 14 Ga. 150~C	242825	Wire,	Red 14 Ga. 150~C
	242831	Wire,	Red 14 Ga. 200~C
242827 Wire, Yellow 14 Ga. 150~	242826	Wire,	White 14 Ga. 150~C
	242827	Wire,	Yellow 14 Ga. 150~C
242832 Wire, Yellow 14 Ga. 200~	242832	Wire,	Yellow 14 Ga. 200~C

REFINISHING MATERIAL

261810 Touch-Up Self-Clean (1/2 Pt.)

261582 Grease

ACCESSORY PARTS

261825 Console


261881 Rotisserie Kit

LITERATURE PARTS

Lit3148392 Tech Sheet

LIT3147380 Instructions, Installation

Lit3147429 Guide, Use & Care Lit3149670 Book, Cooking Guide LIT884832 List, Repair Parts



Note: The Screws And Nuts Required To Attach A Part Are Listed Immediately Following That Part.


1	3170856	Front Frame
2	307985	Pin, Hinge Ear (2)
3	309111	Snubber, Door (2)
4	308306	Pushnut (2)
5	310770	Insulation Tray
6	311006	Side Wrapper R.H.
	311009	Side Wrapper L.H.
7	311774	Support, Side Wrapper (4)
	3148107	Screw, #8 x 1/2 (4)
8	311256	Insulation Baffle (2)
	3148442	Screw, $\#6-20x1\ 1/4\ (2)$
9	310693	Baffle, Top Insulation
	3148107	Screw, #8 x 1/2 (4)
10	310685	Side Trim L.H.
	310689	Side Trim R.H.
	3148107	Screw, #8 x 1/2 (8)
11	329003	Oven (30" Pyro)
	311056	Screw (3)
12	310713	Bracket, Oven Mounting (2)
	343641	Screw, 10-16 x 1/2 (6)
13	257314	Plug Button
15	328801	Hinge Ear R.H.
	328802	Hinge Ear L.H.
16	310659	Plate (Side Panel) (2)
	308544	Screw, $10-24 \times 1/2 (4)$
17	329713	Channel Arm (2)
18	307986	Pin, Hinge (2)
19	307594	Ring, Retainer (2)
21	308125	Anchor, Spring (2)
22	308126	Spring, Oven Door (2)
23	3147220	Tube, Vent Extension
	343641	Screw, 10-16 x 1/2
24	310839	Smoke Eliminator
	3148107	Screw, $\#8 \times 1/2 (2)$
26	661170	Unit, Bake
	312318	Screw, $10-32 \times 1/2 (2)$
27	3148040	Unit, Broil
	312318	Screw, $10-32 \times 1/2 (4)$
28	660556	Socket, Oven Light
	308043	Screw, $10-12 \times 7/8 (2)$
29	311255	Bulb, Oven Light
30	308039	Cover, Oven Light
31	308038	Retainer, Oven Light
32	311982	Coverplate
33	3171150	Latch Assembly
	313638	Screw, $8-18 \times 1/2$ (2)
	311056	Screw (2)
34	313309	Safety Switch
	98106	Screw (2)
35	309245	Insulator, Switch
36	313035	Terminal, Shield
	3148107	Screw #8 x 1/2
	309258	Screw #6 x 3/8
37	310825	Latch Handle

```
308422
                  Screw, 10-24 \times 1/2 (2)
                  Knob, Latch Handle
38
      311253
                  Screw, 8 \times 5/16
      246135
                  Switch, Door
39
      310345
40
     3148284
                  Seal
45
     3148440
                  Sensor
46
                  Side Trim
      3149426
                  Black - Left
                  White - Left
      3149428
      3149430
                  Almond - Left
      3149427
                  Black - Right
      3149429
                  White - Right
      3149431
                  Almond - Right
47
                  Bottom Vent
      3149446
                  Black
                  White
      3149447
      3149448
                  Almond
48
      3149458
                  Bracket, Mounting
      3149333
                  Screw #10 \times 1/2  Black (2)
52
     3149542
                  Back Panel
                  Screw, \#8 \times 1/2 (6)
      3148107
53
                  Terminal Block
      258076
      112432
                  Nut (3)
      308043
                  Screw, 10-12 \times 7/8 (2)
54
      310458
                  Cover, Bottom
55
     311592
                  Angle, Support (2)
      3148107
                  Screw, \#8 \times 1/2 (4)
                  Cover, Rear
56
     311012
      3148107
                  Screw, \#8 \times 1/2 (12)
59
                  Pan, Broiler
      3147845
60
      3147563
                  Grid, Broiler Pan
61
      308173
                  Rack, Oven
                  Rack, Oven Offset
62
      308172
FOLLOWING PARTS NOT ILLUSTRATED
      310433
                Insulation, Wrap
      310434
                  Insulation, Oven
```

Insulation, Top

3149328

WIRING HARNESS PARTS For Model: KEDT105VBL1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3149770	Harness, Wire	(Main)
2	3147825	Harness, Wire	(suface Unit)
3	3147269	Harness, Wire	(Infinite Switch)
4	94613	Terminal	
7	313438	Clip, Harness	(2)